
To Turn Projector On or Off
To project a Laptop connected via HDMI
To project a Laptop connected via VGA and 1/8' Audio Out
To Show a DVD
To project the Computer Screen or project using Air Server
To control Volume of Room Speakers
HDMI
VGA
BLU-RAY
PC
VOLUME
CONFIG
Extron
MLC 104 IP PLUS

DVD Remote Storage Location
Please return when finished

Turn DVD Player On or OFF
Insert or Remove DVD
LG
BLU-RAY DISC PLAYER


Projection Screen Switch
Screen Up
Screen Down


To Turn Projector On or Off
To project the ELMO connected via HDMI
To project a Laptop connected via VGA and 1/8' Audio Out
To Show a DVD
To project the Computer Screen or project using Air Server
To control Volume of Room Speakers
HDMI
VGA
BLU-RAY
PC
VOLUME
CONFIG
Extron
MLC 104 IP PLUS

DVD Remote Storage Location
Please return when finished

Turn DVD Player On or OFF
Insert or Remove DVD
LG
BLU-RAY DISC PLAYER


Projection Screen Switch
Screen Up
Screen Down